



Compatibility of *Vision Air* versions with Windows™ operating systems

	Windows XP (SP1/SP2/SP3)	Windows Vista	Windows 7	Windows 8	Windows 10
<i>Vision Air</i> 1.1	-	-	✓	✓	-
<i>Vision Air</i> 2.0	-	-	✓	-	✓

Only 64-bit operating systems are supported

	Windows Server 2008 R2 (32 & 64 bit)	Windows Server 2012 64 bit	Windows Server 2012 R2 64 bit	Windows Server 2016	Windows Server 2019
<i>Vision Air Server</i> 1.1	✓	-	-	-	-
<i>Vision Air Server</i> 2.0–2.0.5	-	✓	✓	-	-
<i>Vision Air Server</i> 2.0.7 or higher	-	-	✓	✓	✓

Operating System Language must be English (during installation only)