

Agilent MetaCarb 87H
Organic Acids Column
H+ Form
User Manual
Part No. A5214

**Warning:** The Agilent MetaCarb 87H organic acids column is packed with a polymeric material that requires special care. Introduction of organic solvents into the column except as described below will cause the polymer to swell and the column will overpressure. The column warranty is invalidated if this occurs. Consequently, prior to installing the column you should thoroughly flush the lines of your LC with iso-propanol followed by de-ionized water for at least one hour to remove any organic solvents. Do not allow iso-propanol to enter the column.

You should thoroughly familiarize yourself with the contents of this manual before using your column. Improper use will invalidate the warranty.



## **Description**

The Agilent MetaCarb 87H column contains a 0.65 x 30 cm bed packed with a cation-exchange resin in the H+ ionic form. It is specifically designed for the separation of weak organic and inorganic acids that are contained in wine, fruit juices, dairy products, physiological samples, industrial formulation and environmental samples. Only an aqueous mobile phase is required to achieve separation of a variety of acids. The primary mode of separation is ion exclusion although steric exclusion and partitioning mechanisms may be involved. Optimum performance is obtained at elevated temperatures; consequently, a column heating device is required. The column's physical dimensions (3/8 in. od x 30 cm) are compatible with most commercially available heaters found in modular and dedicated liquid chromatographs.

# Mobile phase

The recommended mobile phase is dilute sulfuric acid at a concentration between 0.0001 and 0.05 N. Most analysis can be successfully achieved with 0.01 N  $H_2SO_4$  (0.29 mL concentrated sulfuric acid per liter, approximately pH 2.0). Other strong acids, such as perchloric and nitric, can be used; but halide containing acids, such as hydrochloric acid are not recommended due to their corrosive effect on stainless steel. Mobile phases that contain cations other than  $H^+$  will damage the column.

When strong acids are used as the mobile phase, the column is self-regenerating; therefore, special regeneration steps are not usually required. Stronger mobile phases usually increase retention times for most weak acids.

Use of organic modifiers is not recommended. Once an organic modifier is introduced to the column, the column retains the chromatographic characteristics of the mobile phase with modifier and will not perform as originally shipped even if the mobile phase has been returned to the original 100% aqueous composition.

All mobile phases should be filtered through  $0.45~\mu m$  membranes and degassed prior to use. To avoid problems associated with bubble formation in detector flow cells; it is good practice to thoroughly degas your mobile phase daily. This is particularly important when optimum separation requires high column temperatures. In these circumstances, it is advised to purge your mobile phase with helium for at least 15 minutes.

## Mobile phase flow rate

It is good practice to limit mobile phase flow rates such that pump pressure does not exceed 68 atm (1000 psi). The recommended mobile phase flow rate for the Agilent MetaCarb 87H hydrogen form column is 0.6 mL/min. High flow rates accelerate analysis at the expense of resolution; lower flow rates result in improved resolution but slightly longer analysis times. Maximum column separation efficiencies are achieved at the lower flow rates.

## Column pressure

Remember that the pump pressure required to deliver mobile phases through the column is a *consequence* of mobile phase flow rate, column temperature, mobile phase viscosity, etc. Under normal operating conditions, a flow rate of 0.6 mL/min at 35 °C should require pump pressures less than 50 atm. It is inadvisable to utilize mobile phase flow rates that produce pump pressures in excess of 68 atm. It is advisable to set the high pressure limit on your test system at 70 atm. If high pressures result from use of the column at nominal flow rates, this usually indicates that some contaminants have become deposited on the packing material and corrective action must be taken (see section below on "Causes of Performance Loss"). To prevent irreversible damage to the column, however, you must exercise care in preparing mobile phases and samples. High column pressures nearly always result from improper use of the



column. Use of a guard column or cartridges (see below) will usually prevent contaminants from accumulating on the analytical column.

## Mobile phase flow direction

For the best results the column should be operated in the same flow direction as indicated by the arrow on the column body. However, the column can be reversed as needed to flush out contaminants or any particulates that may build up on the inlet end of the column.

### Column temperature

The Agilent MetaCarb 87H column should always be used with a heating device. A particular characteristic of the packing material is the improved efficiency that results from use of the column at elevated temperatures. However, column temperature also influences sample retention and therefore must be carefully maintained to ensure repeatable results. Although temperature can be used to influence certain separations, the temperature range of 30-50 °C has been determined to be the optimum for the Agilent MetaCarb 87H column. Temperatures below 30 °C can be used for some applications but mobile phase pump pressures may be excessive unless flow rates are reduced. If it is necessary to use the column at lower than recommended temperatures, mobile phase flow rates should be adjusted to keep pump pressures below 68 atm (1000 psi).

Note: When the column is used above 80 °C, care must be taken in disposing of column waste. Acids, even at low concentrations are much more corrosive at high temperatures than at room temperature. Severe burns may occur if hot column waste comes in contact with bare skin.

## Pre-column filter

Pre-column filters containing  $0.45-2.0~\mu m$  porosity passivated stainless steel, PEEK, or titanium frits should be used between the sample injector and the column to remove particulates from the mobile phase stream. This will help prevent excessive pressure from developing through the analytical column and will prolong column life.

## **Guard columns**

Guard cartridges should be used with polymeric columns because sample and mobile phase contamination can result in excessive column pressures. Contaminants such as salts and proteins can alter column performance and should always be removed from samples prior to injection onto the column. We recommend Agilent MetaCarb 87H guard cartridges (Cat. No. A5210-GC) for this column. The purchase of a reusable Agilent Guard Holder (Cat. No. A5204) is required in conjunction with the guard cartridges. Cartridge replacement is required when increased column pressure and/or loss of resolution is observed. Silica guard columns are <u>not</u> recommended due to degradation and eventual leakage into the analytical column. Use of guard cartridges should dramatically extend column lifetime and column cleaning or regeneration (described below) should not be required.

# Sample preparation

The key to long column life is proper treatment of the sample prior to injection onto the polymer bed. You should avoid introduction of fats, oils, proteinaceous materials and heavy metal ions into the column by either mobile phases or samples. If possible, you should avoid introduction of particulate matter onto the column. These will ultimately cause an increase in operating pressure and may be difficult or impossible to remove.



Furthermore, certain samples found in the food industry may contain organic matter that is soluble in the food sample, but not in the column environment. Build up of these compounds in the column will lead to plugging and eventual column overpressure. The column can sometimes be regenerated if this occurs (see below), but it is best to avoid deposition of these materials on the polymer bed. Use of guard cartridges also helps prevent this occurrence, providing guard cartridges are replaced frequently. Alternately, the sample can be cleaned off-line using one of the numerous methods of sample purification found in literature. Numerous methods of sample purification can be found in literature, but sample preparation schemes such as those employing solid phase extraction tubes are common.

## Sample volume

lon exclusion and steric exclusion separation modes require small sample volumes to produce the highest separation efficiencies. We recommend sample volumes in the 10-50  $\mu$ L range. Injection of 100  $\mu$ L or more can cause peaks to broaden or merge with nearby peaks.

### .Detection and sensitivity

The mobile phase requirements for the Agilent MetaCarb 87H column enables chromatographers to use a variety of detectors. Spectrophotometers, refractometers, universal, and conductivity detectors can all be used successfully. Remember that sensitivity of detection is ultimately determined by the type of detector chosen; the responsibility of the column is simply to separate the compounds of interest.

## Column storage


The column as supplied is equilibrated with  $0.001~N~H_2SO_4$ . This is also the recommended mobile phase for storage. When the column is stored, be sure the end fittings are tightly sealed using the end plugs provided. Long-term storage without these seals can result in partial drying of packing material and high pressures can ensue. Under these circumstances invert the column and pump de-ionized water at a flow rate of 0.1~mL/min at 35~°C. Gradually increase the flow rate to 0.6~mL/min. Normal pressure should be observed and the column can be used in either direction. If this does not correct the problem, the column may have become contaminated with particulates or other material, or the bed disrupted causing channeling and poor peak shapes.

## Possible causes of performance loss in the Agilent Metacarb 87H

The following outline is intended as an aid in locating sources of performance loss. Because of the nature of polymeric materials and the manufacturing procedures employed by Agilent, it is highly unusual for a column to lose performance due to manufacturing problems. In our experience, nearly all column failures are a result of introduction of contaminants onto the polymer bed or high column pressure beyond recommended limits. Use of guard cartridges will help prevent these problems, as will sample pretreatment (see above). All Agilent columns are thoroughly tested prior to shipment and are supplied with a sample chromatogram illustrating performance of the particular column.

- 1. Post-column mixing and or diffusion make sure the tubing length and tubing id are kept to a minimum
- 2. Improper column temperature
- 3. Improper mobile phase flow rate





- 4. Insufficient equilibration time with mobile phase
- 5. Presence of cations in mobile phase (e.g. Sodium or Iron)
- 6. Polymer contamination
  - a. High column pressure accompanies performance loss
    - (1) particulate accumulation on inlet frit or polymer bed
      - (a) sample origin filter or centrifuge
      - (b) mobile phase origin filter mobile phase; enclose mobile phase reservoirs
      - (c) system origin flush all lines and pump; install in-line system filter
    - (2) protein aceous material accumulation
      - (a) microbial growth in samples
      - (b) microbial growth in mobile phase
    - (3) refractory organic component from food samples
  - b. Normal column pressure accompanies performance loss
    - (1) metal ion contamination
      - (a) inappropriate steel alloy present in LC system
      - (b) samples contaminated with metal ions
    - (2) organic contamination
      - (a) fats, oils, lipids in sample polymer surface becomes coated
      - (b) non-specific organics from improperly prepared mobile phase or source material
      - (c) non-specific organics introduced into mobile phase after preparation (e.g. from atmosphere, during transfer, etc.)
- 7. Bed compression (voids)
  - a. Excessive mobile phase flow rate
  - b. Use of organic modifier (not recommended)

# Operations designed to correct performance losses resulting from polymer contamination or bed compression resulting

The procedures outlined below will, in some cases, restore performance by removing contaminants from the polymer bed. It is important, however, to attempt to locate the source of the problem before again using a column for analysis of samples.

Prepare fresh mobile phase. In some cases, performance loss is traced to mobile phase contamination.
 Therefore, prepare fresh mobile phase and flush all liquid lines before using column; mobile phases should be filtered through 0.2 to 0.45 micron membranes and de-gassed prior to use.



- 2. **"Loosening" the polymer bed.** Many polymers lack the rigidity associated with silica materials and can compress or collapse if inappropriately high mobile phase flow rates are utilized. They are resilient, however, and the compression is reversible except in less severe cases. To correct collapsed beds, shut off the pump and allow the polymer to "relax" for approximately 30 minutes. Invert the column and pump mobile phase at 0.1 mL/min overnight at 65 °C. Return column to normal operating conditions.
- 3. Cleaning of polymer and regeneration. If performance problems persist and particularly if high column pressures remain, an attempt should be made to clean the column to remove built-up contaminants. Cleaning and regeneration procedures outlined below will in some cases restore performance by removing contaminants from the polymer bed. It is important, however, to attempt to locate the source of the problem before again using the column for analysis of samples.

Prepare an aqueous solution of 0.05 N H<sub>2</sub>SO<sub>4</sub>. Set column temperature to  $65 \,^{\circ}\text{C}$  and pump acid solution through (inverted) column at normal mobile phase flow rates. Monitor column back pressure carefully to guard against overpressure. If necessary, adjust mobile phase flow rate such that pressure does not exceed  $68 \, \text{atm.}$  Pump this solution through the column for two hours (overnight for severely contaminated columns).

Column Checking: Return column temperature to normal. Operate column in normal analytical mode with normal mobile phase, but in the inverted position. If performance does not return, orient column in normal direction and repeat. Note that it may take some time for the baseline to stabilize.

- 4. Invert column. If performance problems persist, column should be inverted and operated under standard analytical conditions. If performance returns to normal, continue operation in this configuration. If performance does not improve, polymer may be permanently contaminated and column may require replacement.
- Column replacement. The procedures above will restore performance only in certain cases. Heavy metal contamination and certain organic contaminants are particularly refractory and may not respond to treatment. Under these circumstances, column replacement is necessary. It is highly advisable to locate the cause of the problem before installing a new column. Consult the manufacturer of your LC system for aid in this matter.

## Column lifetime

To extend column lifetime, please keep in mind the following:

- 1. The only recommended mobile phase is acid diluted in distilled, de-ionized water. It should be filtered through a 0.2-0.45 µm membrane and degassed prior to use.
- 2. The recommended flow rate is 0.6 mL/min. Higher flow rates may be used as long as pressure is below recommended maximum pressure. Increasing temperature allows for the use of higher flow rates.
- 3. Use recommended in-line filter and guard column or cartridges.
- 4. Adjust flow rate to keep column back pressures below 68 atm (1000 psi).



5.	When the column is not to be used for extended periods, store equilibrated in 0.001 N $H_2SO_4$ .
6.	Filter samples through 0.2-0.45 micron membrane before injection.
7.	Use HPLC grade or better chemicals for all work. Discard any solutions that show evidence of bacterial growth.
ww	<u>w.agilent.com</u>
	ent shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or of this material
Info	rmation, descriptions, and specifications in this publication are subject to change without notice.
A50	gilent Technologies, Inc. 2013 214 -2937EN
วยยา	-293/EIN
7	The Measure of Confidence Agilent Technologies